

REFRESHING LEG LOTION

No. 840

Phase	Trade Name	INCI	%	Function
A	IMWITOR® 375	Glyceryl Citrate/Lactate/Linoleate/Oleate	2.0	O/W Emulsifier
A	IMWITOR® 900 K	Glyceryl Stearate	1.0	Co- Emulsifier
A	NAFOL® 1618H	Cetearyl Alcohol	2.0	Consistency Agent
A	MIGLYOL® T-C7	Triheptanoin	2.0	Light Emollient
A	MIGLYOL® Coco 810	Coco-Caprylate/Caprate	5.0	Light Emollient
A	MIGLYOL® DO	Decyl Oleate	5.0	Emollient
A	SOFTISAN® 378	Caprylic/Capric/Myristic/Stearic Triglyceride	2.0	Structure Imparting Agent
A	Cosphaderm® X-Soft	Xanthan Gum	0.6	Gelling Agent
A	Frescolat® X-Cool	Menthyl Ethylamido Oxalate	2.0	Cooling Agent
B	Water demin.	Aqua	68.6	Diluent
B	Cosphaderm® Pop	Propanediol (and) Caprylyl Glycol (and) Phenylpropanol	1.2	Alternative Preservative
B	Zemea® Propanediol	Propanediol	5.0	Humectant
C	Unicert Green K7015-J	Aqua (and) CI 61570	0.2	Color
C	Unicert Yellow 08005-J	Aqua (and) CI 19140	0.3	Color
C	Oceania 49384079	Parfum (EU)/ Fragrance (US)	0.3	Parfum



IOI OLEOCHEMICAL

IOI Oleo GmbH
PERSONAL CARE

Visit us at www.ioioleo.de or send us an e-mail to personalcare@ioioleo.de
IOI Oleo GmbH – Herrengraben 31 – 20459 Hamburg, Germany - +49 40 280 031 0

Preparation

1. Weigh both phases A and B and heat them separately to approx. 70-80°C.
2. Add phase B to phase A and homogenize (3 min @ 12.000 rpm).
3. Allow to cool (35-40°C) while stirring.
4. Adjust the pH to pH 5.8-6.0 if necessary.

Suppliers

IOI Oleo	IMWITOR®, MIGLYOL®, SOFTISAN®
Sasol	NAFOL®
Cosphatec	Cosphaderm®
DuPont Tate & Lyle	Zemea®
Symrise	Frescolat®
Sensient	Unicert
drom	Parfum

REFRESHING

CARING

SMOOTH SKIN

Stable for three months @ 40°C



IOI OLEOCHEMICAL

IOI Oleo GmbH
PERSONAL CARE

Visit us at www.ioioleo.de or send us an e-mail to personalcare@ioioleo.de
IOI Oleo GmbH – Herrengraben 31 – 20459 Hamburg, Germany - +49 40 280 031 0